



# SMART Board™ for DViT™ (Digital Vision Touch) Flat-Panel Displays and Actalyst™ Interactive Digital Signage – No Digital Ink

**Flowchart 1: Getting Started**



## Flowchart 2: Flat-Panel Display




To connect your SMART Board for flat-panel displays, refer to "Installing the Interactive Whiteboard" in your [SMART Board for Flat-Panel Displays Interactive Whiteboard Installation Guide](#).

SMART Notebook software 10 includes SMART Notebook software and SMART Product Drivers (formerly SMART Board drivers).

You can install SMART Notebook software 10 from the CD provided with your interactive whiteboard, or you can download it from [SMART's website](#).

To put a SMART product in projected mode, go to the SMART Notebook control panel and press **SMART Hardware Settings > Hardware Info and Settings**, and then select **Projected (Mouse Mode)**.

### Flowchart 3: Actalyst Overlay



You can install Actalyst software from the CD provided with your interactive overlay, or you can download it from [SMART's website](#).