

How to Enable Bluetooth® Wireless Support on Your Computer



Applies to: The AirLiner™ WS100 wireless slate

Issue

This document describes how to enable Bluetooth® wireless support on your computer.

Solution

To wirelessly connect your computer to your slate, the computer must have either an installed USB-to-Bluetooth wireless adapter or built-in Bluetooth wireless support. Do one of the following:

- Install the provided Bluetooth wireless adapter. For more information, see the instructions that came with the adapter.
- Purchase and install a commercially available USB-to-Bluetooth wireless adapter. For more information, see the instructions that came with the adapter.
- Enable your computer's built-in Bluetooth wireless support, if available. For more information, see the instructions that came with your computer.

NOTE: Most computers don't have built-in Bluetooth wireless support.

First Published: May 3, 2006

Last Updated: November 9, 2007

SMART Technologies
1207 – 11 Avenue SW, Suite 300
Calgary, AB T3C 0M5
CANADA



www.smarttech.com/support www.smarttech.com/contactsupport
Support +1.403.228.5940 or Toll Free 1.866.518.6791 (Canada/U.S.)

© 2006–2007 SMART Technologies ULC. All rights reserved. AirLiner, smarttech and the SMART logo are trademarks or registered trademarks of SMART Technologies ULC in the U.S. and/or other countries. The Bluetooth word mark is owned by the Bluetooth SIG, Inc. and any use of such marks by SMART Technologies ULC is under license. All other third-party product and company names may be trademarks of their respective owners. Patent No. US5448263; US6141000; US6326954; US6337681; US6741267; US6747636; US7151533; and CA2058219. Other patents pending. Contents are subject to change without notice. 11/2007.